

I see that the DCR100 has a configuration feature called Operating Mode, What does this mean?

Article Number: 666 | Rating: Unrated | Last Updated: Wed, Jan 24, 2018 7:21 PM

DCR100 channels have two possible operating modes: “Normal”, in which the DCR100 channel responds to standard NMEA 2000 switching commands, and “Annunciator”, in which the channel may be connected to a power source for a sounder or a light to be activated in the case of an alert generated by a DSM150, DSM410, or DSM250 display, or by N2KView software.

Posted - Thu, Mar 23, 2017 5:23 PM. This article has been viewed 675 times.

Online URL: <https://www.maretron.com/support/knowledgebase/phpkbv7/article.php?id=666>