How do I display the GPS100 moon phase on Maretron's DSM150, DSM200, or DSM250 display?

The GPS100 doesn't actually compute and transmit the phase of the moon over an NMEA 2000 network. However, the DSM150, DSM200, and DSM250 receive enough information from the GPS100 (time and position) to compute the phase of the moon. You display the moon phase on a DSM150, DSM200, or DSM250 in the following way:

1. Enter menu mode, scroll to "Favorite Screen Setup..." and press
2. Scroll to the favorite screen where you would like to view the moon phase and press
3. Scroll to "Data:" and press
4. Scroll to "Time" and press
5. Scroll to "Moon Phase" and press
6. Press the key three times to exit menu mode and return to the normal viewing mode
7. Scroll through your screens to the favorite screen you selected for Moon Phase