

How do I display the GPS100 latitude and longitude or position using Maretron's DSM150, DSM200, or DSM250 display?

You display the GPS100 position information on a DSM150, DSM200, or DSM250 in the following way.

1. Enter menu mode, scroll to "Favorite Screen Setup..." and press
2. Scroll to the favorite screen where you would like to view the position and press
3. Scroll to "Data:" and press
4. Scroll to "GPS" and press
5. Scroll to "Lat/Lon" and press
6. Press the key three times to exit menu mode and return to the normal viewing mode.
7. Scroll through your screens to the favorite screen you selected for position.

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=146>