

How do I reset the GPS100 to send the factory default NMEA 2000 messages (or PGNs)?

You reset the GPS100 to transmit the factory default messages using Maretron's DSM150 or DSM250 display in the following way.

1. Enter menu mode, scroll to "Configuration..." and press
2. Scroll to "Device Configuration..." and press
3. Scroll to the row containing the GPS100 and press
4. Scroll to "Reset Factory Defaults" and press twice.

Beware that resetting factory defaults resets all settings back to factory defaults, not just the transmitted messages.

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=167>