How do I reset the DST100 total distance log?

The DST100 total distance log is not resettable. The total distance log indicates the total distance traveled since the DST100 was purchased and installed in the vessel.