

How do I display the WSO100 true wind referenced to water speed on Maretron's DSM150, DSM200, or DSM250 display?

You display the WSO100 true wind on a DSM150, DSM200, or DSM250 in the following way:

1. Enter menu mode, scroll to "Favorite Screen Setup..." and press
2. Scroll to the favorite screen where you would like to view the true wind and press
3. Scroll to "Data:" and press
4. Scroll to "Wind" and press
5. Scroll to either "Dir. True" or "Speed True" and press
6. Press the key three times to exit menu mode and return to the normal viewing mode
7. Scroll through your screens to the favorite screen you selected for true wind

To show the true wind relative to water speed, make sure that the DSM150, DSM200, or DSM250 is set to "Water" under the units setting "Wind True Vessel Ref:"

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=22>