

I see that Maretron's DSM150 and DSM250 displays have a DCM100 configuration setting called "Instance: "; what is this?

Maretron's DSM150 and DSM250 displays have a DCM100 configuration setting called "Instance:", which is used to program the DCM100 to transmit the appropriate NMEA 2000 instance. For example, if the DCM100 is connected to a DC source, then this configuration setting would be used to program the DCM100 to transmit instance 0, allowing the user to determine which DC source is viewed.

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=347>