

How do I set the WSO100 outside humidity offset using Maretron's DSM150 or DSM250 display?

You set the WSO100 outside humidity offset using Maretron's DSM150 or DSM250 display in the following way:

1. Enter menu mode, scroll to "Configuration..." and press
2. Scroll to "Device Configuration..." and press
3. Scroll to the row containing the WSO100 and press
4. Scroll to "Outside Humidity:" and press
5. Scroll up or down until you set the appropriate outside humidity and press

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=39>