# I do not see video within N2KView Camera Setup; what does this mean?

If you have set the camera configuration and video still does not appear, please do the following:

- Confirm the PC or Maretron Display is connected to the LAN network a camera is installed.
- Run the Axis Camera Setup tool and confirm that the camera is visible in the list of cameras displayed by the tool.
- Confirm that the IP address of the camera matches the IP address you have set in the Camera Setup of N2KView.
- Confirm that port 80 is not blocked by your computer's firewall

software.