

How do I connect my N2KView to the IPG100?

N2KView offers several different ways for connecting to a Maretron gateway (IPG100, USB100, Maretron Cloud Services). To connect to an IPG100 on a vessel's LAN Network, please do the following:

1. Touch the screen to display the command and screen tabs
2. Select the "Commands & Settings" tab
3. In the "Commands & Settings" window, select "Connections"
4. A "Connections Settings" window will appear
5. Any IPG100 gateways found on the local network will appear in the "Available Connections" list
6. Select one of the IPG100's and then click on "Use Selected as 1st Connection"
7. The "Use 1st Connection" checkbox will become checked, the network connection type will be set to "LAN" and the "Serial Number" textbox will be filled with the selected IPG100's serial number
8. You can now click "Connect" at the bottom of the "Connections Settings" window to establish an NMEA 2000 connection to the selected gateway.

Please watch the video below.

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=598>