

Can you mix AC and DC loads on the same RIM100?

Yes, each channel is optically isolated allowing the end users to “mix and match” the load types you are interested in monitoring.

Please take note of the proper wiring installation for both the AC and DC load connections.




Figure 3 – AC Single-Phase (Ph. A) Load Connection Diagram

