

## **How do I set the DCM100 configuration setting called "Instance:" using Maretron's DSM250 display?**

Article Number: 348 | Rating: Unrated | Last Updated: Mon, Jun 2, 2014 9:25 PM

You set the DSM100 configuration setting called " Instance:" using Maretron's DSM250 display in the following way. Enter menu mode, scroll to "Configuration..." and press enter. Scroll to "Device Configuration..." and press enter. Scroll to the row containing theDCM100 and press enter. Scroll to "Instance:" and press enter. Scroll until you find the appropriate instance 0-252 and press enter.

Posted - Fri, Nov 7, 2008 5:45 PM. This article has been viewed 3561 times.

Online URL: <https://www.maretron.com/support/knowledgebase/phpkbv7/article.php?id=348>