

## How do I set a "Device Instance" for a Maretron sensor using the DSM250?

Article Number: 360 | Rating: Unrated | Last Updated: Mon, Jun 2, 2014 9:20 PM

To set a "Device Instance" for a Maretron sensor using the DSM250, simply press the enter key (far right hand button) to view the "Menu Mode", scroll to "Configuration", hit enter, select "Device Configuration", hit enter, scroll to the desired device you wish to change the instance on, press enter, scroll to "Advanced Configuration" , hit enter, scroll to "Instance" press enter, scroll to the desired Instance press enter.

Posted - Tue, Sep 1, 2009 11:54 AM. This article has been viewed 3558 times.

Online URL: <https://www.maretron.com/support/knowledgebase/phpkbv7/article.php?id=360>