

How do I display the DST100 transducer offset on Maretron's DSM150, DSM200, or DSM250 display?

You display the DST100 transducer offset on a DSM150, DSM200, or DSM250 in the following way:

- Enter menu mode, scroll to "Favorite Screen Setup..." and press
- Scroll to the favorite screen where you would like to view the transducer offset and press
- Scroll to "Data:" and press
- Scroll to "Depth" and press
- Scroll to "Transducer Offset" and press
- Press the key three times to exit menu mode and return to the normal viewing mode
- Scroll through your screens to the Favorite Screen you selected for transducer offset

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=185>