

How do I set the DCM100 configuration setting called "Instance:" using Maretron's DSM250 display?

You set the DSM100 configuration setting called " Instance:" using Maretron's DSM250 display in the following way. Enter menu mode, scroll to "Configuration..." and press enter. Scroll to "Device Configuration..." and press enter. Scroll to the row containing theDCM100 and press enter. Scroll to "Instance:" and press enter. Scroll until you find the appropriate instance 0-252 and press enter.

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=348>