

## How do I transfer display settings from one DSM150 or DSM250 to another DSM150 or DSM250 on the same NMEA 2000 network?

The DSM250 has the ability to clone its settings to another DSM250 display on the same NMEA2000 network. For example if you want one DSM250 in one part of the ship to have the same settings as the helm DSM250 follow these simple steps.

1. Go to the DSM250 that has the settings you wish to transfer.
2. If the unit is in its favorite screen mode, press to display the menu
3. Scroll to "Configuration..." and press
4. Scroll to "Device Configuration..." press
5. Scroll to the DSM250 you wish to transfer settings to, and press
6. Choose from the following list of options and press

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=469>