

## How do I set the TLA100 tank number or instance using Maretron's DSM150, DSM200, or DSM250 display?

You set the TLA100 tank number or instance using Maretron's DSM150, DSM200, or DSM250 display in the following way:

1. Enter menu mode, scroll to "Configuration:" and press
2. Scroll to "Device Configuration:" and press
3. Scroll to the row containing the TLA100 and press
4. Scroll to "Tank Number:" and press
5. Scroll until you find the appropriate tank number and press

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=57>