

How do I set the TLA100 operating mode using Maretron's DSM150, DSM200, or DSM250 display?

You set the TLA100 operating mode using Maretron's DSM150, DSM200, or DSM250 display in the following way:

1. Enter menu mode, scroll to "Configuration:" and press
2. Scroll to "Device Configuration:" and press
3. Scroll to the row containing the TLA100 and press
4. Scroll to "Operating Mode:" and press
5. Scroll until you find the appropriate operating mode and press

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=61>