

## **I see that Maretron's DSM150, DSM200 and DSM250 displays have a WSO100 configuration setting called "Installation Offset Calibration..."; what is this?**

Article Number: 17 | Rating: Unrated | Last Updated: Sun, Jul 12, 2015 10:12 PM

Maretron's DSM150, DSM200 and DSM250 displays have a WSO100 configuration setting called "Installation Offset Calibration...", which is used to electronically align the WSO100 with the vessel. Although the WSO100 can be mechanically aligned with the vessel, it is difficult to do this with any precision during installation. This configuration setting allows the WSO100 to be precisely aligned with the vessel.

Posted - Mon, Jul 21, 2008 2:12 PM. This article has been viewed 4059 times.

Online URL: <https://www.maretron.com/support/knowledgebase/phpkbv7/article.php?id=17>