

How do I set the RAA100 operating mode using Maretron's DSM150, DSM200, or DSM250 display?

You set the RAA100 operating mode using Maretron's DSM150, DSM200, or DSM250 display in the following way. Enter menu mode, scroll to "Configuration..." and press enter. Scroll to "Device Configuration..." and press enter. Scroll to the row containing the RAA100 and press enter. Scroll to "Operating Mode:" and press enter. Scroll until you find the appropriate operating mode and press enter.

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=275>