

How do I display the TLA100 tank remaining on Maretron's DSM150, DSM200, or DSM250 display?

You display the TLA100 tank remaining on a DSM150, DSM200, or DSM250 in the following way:

1. Enter menu mode, scroll to "Favorite Screen Setup..." and press
2. Scroll to the favorite screen where you would like to view the tank remaining and press
3. Scroll to "Data:" and press
4. Scroll to "Tank-xxxx #y" (where xxxx is the tank type like "Fuel", "Fresh Water", etc. and y is the tank number) and press
5. Scroll to "Remaining" and press
6. Press the key three times to exit menu mode and return to the normal viewing mode
7. Scroll through your screens to the favorite screen you selected for tank remaining

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=53>