

How do I display the DC Time Remaining on the DSM150 or DSM250 display?

You display the DC Time Remaining on the DSM150 or DSM250 in the following way. Enter menu mode, scroll to "Favorite Screen Setup..." and press **Enter**. Scroll to the favorite screen where you would like to view the DC Time Remaining and press **Enter**. Scroll to "Data:" and press **Enter**. Scroll to "DC #*x*" where *x* is the DC instance you want to view and press **Enter**. Scroll to "DC Time Remaining" and press **Enter**. Choose component type (gauge, half gauge, or numeric) and press **Enter**, Press the **Back** key three times to exit menu mode and return to the normal viewing mode. Scroll through your screens to the favorite screen you selected for DC Time Remaining.

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=343>