

# How do I set the WSO100 outside temperature offset using Maretron's DSM150 or DSM250 display?

You set the WSO100 outside temperature offset using Maretron's DSM150 or DSM250 display in the following way.

1. Enter menu mode, scroll to "Configuration..." and press
2. Scroll to "Device Configuration..." and press
3. Scroll to the row containing the WSO100 and press
4. Scroll to "Outside Temperature:" and press
5. Scroll up or down until you set the appropriate outside temperature and press

Online URL:

<https://www.maretron.com/wp-content/phpkbv96/article.php?id=37>